



## CONNECTING TO EPSON PROJECTORS IN CLASSROOMS

### FOR WINDOWS COMPUTERS:


1. For Dell: go to Software Center and install Epson iProjection on your computer.



2. Launch Epson iProjection from your windows start menu. The first time you launch there will be a screen that asks if you will use Advanced or Quick connection. Select Advanced and check box that says “Set the selected Connection Mode as the default mode for future connections.”




3. Turn on Epson projector with remote and depress the LAN key. That will give you the IP address of the projector. This screen should pop-up on your computer, enter LAN address of projector and click join in bottom right corner.



4. If you would like to save this projector for faster connection. Click register and name the projector such as “KES Rm 100”.

5. Your computer should join projector if everything is set up correctly.



6. When ready to disconnect from the projector, click the Leave button.

